



Packing List: Accessory Kit (781078) 1966-67 Dodge Charger, Coronet with Factory Air

No.	Qty.	Part No.	Description
1.	3	06200-VUE	Duct Hose, 2"
2.	11	06250-VUE	Duct Hose, 2 1/2"
3.	2	496130	Louver Hose Adapter, Driver/Passenger Side Assembly
4.	1	496127	Louver Hose Adapter, Center
5.	1	496116	Hose Adapter, Defrost Duct
6.	1	496135	Glove Box
7.	1	496140	Defrost Duct, Passenger Side Assembly
8.	1	232600-VUA	Wiring Kit, Gen IV Universal
9.	1	644118	Bracket Kit, Evaporator
10.	1	644111	Cowl Cover
11.	1	644116	Firewall Cover
12.	1	633152	Installation Kit
13.	1	474157	Control Panel Conversion Kit

Checked By: _____
Packed By: _____
Date: _____

